

RAPIDLOCK

RAPIDLOCK
ORIGINAL DESIGN

QUICK-FIT METAL SYSTEM INSTRUCTIONS

Step 1: Mark & Drill Post Holes



Mark out and drill all of your posts at the required spacing and hole size. This system requires a 10mm hole in end posts and at least a 4mm hole in the intermediate posts.

Step 2: Insert Threaded Inserts



Use the HN-02 nut rivet tool to insert all left hand nut rivets into left hand post and all right hand nut rivets into right hand end post.

Step 3: Pass Wire Through Posts



Pass the wire through any pre-drilled intermediate posts.

Step 4: Rapid Lock the Wire



Firmly push the wire into the opening of the right hand threaded Rapid Lock Swageless Stud so that contact with the internal back end can be felt. Rapid Lock's patented one-way jaw system will lock the wire in place.

Step 5: Screw in RHT Stud



Thread the right hand threaded Rapid Lock Stud clockwise into the right hand threaded insert. Rotate 2 full turns.

Step 6: Screw in LHT Stud



At the other end thread the left hand threaded Rapid Lock Stud anticlockwise into the left hand threaded nutsert. Rotate 2 full turns.

Step 7: Cut & Rapid Lock the Wire




Pull the wire tight and hold against the body of the left hand threaded Rapid Lock stud. Cut the wire in line with the edge of the stud where the thread starts. Firmly push the wire into the opening of the left hand threaded Rapid Lock Swageless Stud.

Step 8: Tension Wires



Wind the left hand Rapid Lock stud anticlockwise into the left hand threaded insert, and take note that the other end is rotating and tensioning at the same rate. Continue to wind by hand until the wire is mostly tensioned, then complete using the Rapid Lock Multi Tool.

Step 9: Lock System in place



Once the desired tension has been achieved lock the system in place by tightening the hex nuts against the head of the threaded inserts. Repeat Steps 3-8 until the section has been completed. Repeat on all sections.

RAPIDLOCK

RAPIDLOCK
ORIGINAL DESIGN

QUICK-FIT METAL SYSTEM INSTRUCTIONS

Quick-Fit System



The Rapid Lock Original Design QuickFit metal system offers one of the most streamline wire balustrade systems available on the market. With no special tools required for installation, Rapid Lock's patented one-way jaw system will lock the wire in place by simply pushing the wire into the fittings.

2 x SBRNL-064

2 x SBRNR-064

1 x R7801R-030635

1 x R7801L-030635



M6 ProRig LHT
Blind Nut rivet 0.7-4.0mm
304 Grade stainless Steel

M6 ProRig RHT
Blind Nut rivet 0.7-4.0mm
304 Grade stainless Steel

M6 x 35mm RHT Rapid Lock Stud
316 Grade Stainless Steel

M6 x 35mm LHT Rapid Lock Stud
316 Grade Stainless Steel

Recommended Wire Rope



W03.2119
Designed for use with ultra bright 3.2mm
1 x 19 ProRig 316 grade stainless steel wire rope


Recommended Tools For Installation

Power Drill
CSPAN-MT1 - C-Spanner Multi Tool
RLK-01 - Rapid Lock Release Key
HN-02 - Nutrivet Tool

Recommended Drill Bits For Installation

DCB-040 4mm Cobalt drill bits
DCB-10.0 10mm Cobalt drill bits

Patented One-Way Jaw System



Cut



Push In



Wire Locked



Release Key - Unlocks

Metal Posts Only
Only suitable for use
with metal posts.

MAX RUN LENGHT
10 METERS
Indicates maximum recommended
wire run lengths for each system.